



Ultimate Bull Bar

Application Chart

START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2007	2013	Cadillac	Escalade 1500 ESV/EXT3,14 (excl. Platinum)	3"	32-2130	32-2135	75-0729
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2007	2013	Chevy	Avalanche 1500, 3,14	3"	32-2110	32-2115	75-0721
2002	2006	Chevy	Avalanche 1500, 3,6	3"	32-1170	32-1175	75-0377
2002	2006	Chevy	Avalanche 2500, 3,6	3"	32-1240	32-1245	75-0378
1992	1994	Chevy	Blazer, Fullsize, 3,6	3"	32-0080	32-0085	75-0379
1988	1998	Chevy	C/K Series 1500, 3,6	3"	32-0080	32-0085	75-0379
1988	2000	Chevy	C/K Series 2500/3500, 3,6	3"	32-0080	32-0085	75-0379
2004	2012	Chevy	Colorado - 2/4 WD, 8,9	2.5"	33-1510	33-1515	75-0844
2007	2013	Chevy	Silverado 1500, 18	3"	32-2270	32-2275	75-0767
1999	2007	Chevy	Silverado "Classic" 1500LD, 2,3,6	3"	32-1170	32-1175	75-0377
2011	2013	Chevy	Silverado 2500HD/3500, 3,6	3"	32-2320	32-2325	75-0061
2007	2010	Chevy	Silverado 2500HD/3500, 3,6,18	3"	32-2310	32-2315	75-0802
2001	2007	Chevy	Silverado "Classic" 1500HD/2500HD/3500, 2,3,6	3"	32-1240	32-1245	75-0378
1999	2007	Chevy	Silverado "Classic" 2500LD, 2,3,6	3"	32-1240	32-1245	75-0378
2007	2011	Chevy	Suburban - 15003,14 (excl. Hybrid)	3"	32-2110	32-2115	75-0721
2000	2006	Chevy	Suburban - 1/2 ton (1500), 3,6	3"	32-1170	32-1175	75-0377
2000	2006	Chevy	Suburban - 3/4 ton (2500), 3,6	3"	32-1240	32-1245	75-0378
1992	1999	Chevy	Suburban - All, 3,6	3"	32-0080	32-0085	75-0379
2007	2013	Chevy	Tahoe - 1500 (excl. Hybrid), 3,14	3"	32-2110	32-2115	75-0721
2000	2006	Chevy	Tahoe - 1/2 ton (1500), 3,6	3"	32-1170	32-1175	75-0377
2000	2006	Chevy	Tahoe - 3/4 ton (2500), 3,6	3"	32-1240	32-1245	75-0378
1995	1999	Chevy	Tahoe - All, 3,6	3"	32-0080	32-0085	75-0379
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2006	2009	Chrysler	Aspen, 1,3,7	3"	32-1540	32-1545	—
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2005	2011	Dodge	Dakota, 3,7	3"	32-1660	32-1665	75-0499
1997	2004	Dodge	Dakota	3"	32-0140	32-0145	75-0431
2011	2013	Dodge	Durango, 23	3"	32-3580	32-3585	75-0036
2004	2010	Dodge	Durango, 1,3,7	3"	32-1540	32-1545	75-0430
1998	2003	Dodge	Durango	3"	32-0140	32-0145	75-0431
2007	2011	Dodge	Nitro	2.5"	33-2350	33-2355	75-0774
2009	2013	Dodge	Ram 1500	3"	32-1960	32-1965	—
2006	2008	Dodge	Ram 1500, 1,12,13,17	3"	32-1950	32-1955	75-0608
2002	2005	Dodge	Ram 1500, 3,5,17	3"	32-1200	32-1205	75-0371
1994	2001	Dodge	Ram 1500 (excl. 99-01 Sport models), 1	3"	32-0600	32-0605	75-0372
2010	2012	Dodge	Ram 2500/3500, 3	3"	32-3550	32-3555	75-1027
2006	2009	Dodge	Ram 2500/3500, 1,12	3"	32-1970	32-1975	75-0608
2003	2005	Dodge	Ram 2500/3500, 3,5,12	3"	32-1200	32-1205	75-0371
1994	2002	Dodge	Ram 2500/3500 (excl. 99-02 Sport models), 1	3"	32-0600	32-0605	75-0372
2008	2009	Dodge	Ram 4500/5500	3"	32-1970	32-1975	75-0608
2006	2009	Dodge	Ram Mega-Cab, 1	3"	32-1970	32-1975	75-0608
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2008	2012	Ford	Escape/Escape Hybrid, 23	2.5"	33-2060	33-2065	75-0830
2005	2005	Ford	Excursion	3"	32-1640	32-1645	75-0380
2000	2004	Ford	Excursion	3"	32-0220	32-0225	75-0380

2003	2012	Ford	Expedition, EL3	3"	32-2400	32-2405	75-0800
1997	2002	Ford	Expedition 4WD (99-02 - 2WD), 6	3"	32-0240	32-0245	75-0373
2011	2013	Ford	Explorer, 1, 23	3"	32-3570	32-3575	75-0083
2006	2010	Ford	Explorer, 8	2.5"	33-2030	33-2035	75-0615
2002	2005	Ford	Explorer, 1	2.5"	33-0970	33-0975	75-0514
2007	2010	Ford	Explorer Sport Trac, 8	2.5"	33-2030	33-2035	75-0615
2009	2012	Ford	F150, 1,21,22	3"	32-2400	32-2405	—
2004	2008	Ford	F150 2/4WD (excl. Heritage edition), 3,7,16	3"	32-1390	32-1395	75-0411
1999	2004	Ford	F150/250LD - 2WD, 4,6,15	3"	32-0240	32-0245	75-0373
1997	2004	Ford	F150/250LD - 4WD, 4,6,15	3"	32-0240	32-0245	75-0373
2001	2003	Ford	F150 Super Crew	3"	32-0240	32-0245	75-0373
2011	2013	Ford	F250/350/450/550HD Super Duty	3"	32-2370	32-2375	
2008	2010	Ford	F250/350/450/550HD Super Duty	3"	32-2360	32-2365	75-0776
2005	2007	Ford	F250/350/450/550HD Super Duty, 16	3"	32-1640	32-1645	75-0380
1999	2004	Ford	F250/350/450/550HD Super Duty, 16	3"	32-0220	32-0225	75-0380
1998	2000	Ford	Ranger, 10	2.5"	33-0880	33-0885	75-0440
2001	2011	Ford	Ranger	2.5"	33-2360	33-2365	75-0440
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
1988	1998	GMC	C/K Series 1500, 3,6	3"	32-0080	32-0085	75-0379
1988	2000	GMC	C/K Series 2500/3500, 3,6	3"	32-0080	32-0085	75-0379
2004	2012	GMC	Canyon - 2/4WD, 8,9	2.5"	33-1510	33-1515	75-0844
1992	1994	GMC	Jimmy - Fullsize, 6	3"	32-0080	32-0085	75-0379
2007	2013	GMC	Sierra 1500 (excl. Denali), 18	3"	32-2270	32-2275	75-0767
1999	2007	GMC	Sierra "Classic" 1500LD, 3,6	3"	32-1170	32-1175	75-0377
2011	2013	GMC	Sierra 2500HD/3500, 3,6	3"	32-2320	32-2325	—
2007	2010	GMC	Sierra 2500/3500, 3,6,18	3"	32-2310	32-2315	75-0802
2001	2007	GMC	Sierra "Classic" 1500HD/2500/3500HD, 3,6	3"	32-1240	32-1245	75-0378
1999	2007	GMC	Sierra "Classic" 2500LD, 3,6	3"	32-1240	32-1245	75-0378
2007	2013	GMC	Yukon/Yukon XL - 1500 (excl. Denali & Hybrid), 3,14	3"	32-2110	32-2115	75-0721
2000	2006	GMC	Yukon/Yukon XL - 1500 (excl. Denali), 3,6	3"	32-1170	32-1175	75-0377
2000	2006	GMC	Yukon/Yukon XL - 3/4 ton (excl. Denali), 3,6	3"	32-1240	32-1245	75-0378
1995	1999	GMC	Yukon, 6	3"	32-0080	32-0085	75-0379
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2002	2008	Honda	Pilot	2.5"	33-1930	33-1935	75-0548
2006	2012	Honda	Ridgeline	2.5"	33-1930	33-1935	75-0548
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2006	2010	Hummer	H33	2.5"	33-1920	—	75-0551
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2006	2008	Isuzu	I-Series, 8	2.5"	33-1510	33-1515	75-0844
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2006	2010	Jeep	Commander, 3	2.5"	33-1990	33-1995	75-0746
2005	2008	Jeep	Liberty, 3	2.5"	33-2350	33-2355	75-0774
2011	2013	Jeep	Grand Cherokee, 23	3"	32-3580	32-3585	75-0036
2005	2007	Jeep	Grand Cherokee, 3	2.5"	33-1990	33-1995	75-0746
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2003	2010	Lexus	GX470 2/4WD	2.5"	33-1280	33-1285	—
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2006	2008	Lincoln	Mark LT, 7	3"	32-1390	32-1395	75-0411
2003	2011	Lincoln	Navigator, L - 2/4WD, 3,24	3"	32-2400	32-2405	75-0800
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2008	2012	Mazda	Tribute	2.5"	33-2060	33-2065	75-0830
2008	2012	Mazda	Tribute Hybrid	2.5"	33-2060	33-2065	75-0830
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2008	2011	Mercury	Mariner	2.5"	33-2060	33-2065	75-0830
2008	2011	Mercury	Mariner Hybrid	2.5"	33-2060	33-2065	75-0830
2006	2010	Mercury	Mountaineer, r8	2.5"	33-2030	33-2035	—

START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2006	2009	Mitsubishi	Raider	3"	32-1660	32-1665	—
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2004	2013	Nissan	Armada - 2/4WD, 3,11,19	3"	32-1480	32-1485	75-0416
2005	2012	Nissan	Frontier, 3,8	3"	32-1690	32-1695	75-0507
2001	2004	Nissan	Frontier, 3	2.5"	—	33-1005	—
2008	2012	Nissan	Pathfinder, 3,8	3"	32-1800	32-1805	75-0507
2005	2007	Nissan	Pathfinder, 3,8	3"	32-1690	32-1695	75-0507
1999	2004	Nissan	Pathfinder	2.5"	—	33-0825	—
2004	2012	Nissan	Titan - King/Crew Cab 2WD, 3	3"	32-1480	32-1485	75-0416
2005	2012	Nissan	Xterra, 3	3"	32-1690	32-1695	75-0507
2002	2004	Nissan	Xterra, 3	2.5"	—	33-1435	—
START	END	MAKE	MODEL	DIAMETER	CHROME	BLACK	INSTALL
2010	2013	Toyota	4-Runner	3"	32-3600	32-3605	75-1026
2003	2009	Toyota	4-Runner	2.5"	33-1280	33-1285	75-0717
2006	2013	Toyota	FJ Cruiser, 11	3"	32-2210	32-2215	75-0811
2008	2012	Toyota	Highlander (excl. Hybrid), 1	2.5"	33-1020	33-1025	75-0867
2008	2013	Toyota	Sequoia, 3	3"	32-2250	32-2255	75-0763
2001	2007	Toyota	Sequoia, 3	3"	32-1360	32-1365	75-0402
2005	2013	Toyota	Tacoma, 11	3"	32-1600	32-1605	75-0444
1998	2004	Toyota	Tacoma	2.5"	33-0900	33-0905	—
2007	2013	Toyota	Tundra, 3, 24	3"	32-2250	32-2255	75-0763
1999	2006	Toyota	Tundra, 3	3"	32-1360	32-1365	75-0402

Footnotes:**Apply to E-Series & Ultimate Bull Bar**

- Cutting of the Air dam is required.
- Excludes Silverado S.S. models.
- Tow hooks must be removed.
- Heritage Edition only.
- Filler panel must be removed (if equipped)
- Cutting of the air dam may be required on 2WD models.
- On vehicles w/out tow hooks, minor cutting of air dam is required.
- Minor trimming of air dam may be required.
- Excludes 2WD, 5 cylinder and 4WD, V8 "Off-Road" package.
- If equipped with plastic shroud, it must be removed to complete installation.
- Skid Plate must be removed, if equipped.
- Excludes Power Wagon Package.
- Excludes Hemi-Sport Model.
- Minor trimming of the tow hook pockets required.
- Excludes STX models.
- Excludes Harley Davidson Edition.
- Excludes Daytona/Rumble Bee & SRT-10
- New 2007 body style
- Will not work on Platinum Edition models equipped with front parking sonar system.
- May Partially cover license plate. Use License Plate Relocator PN#32-0055 (sold separately).
- Excludes "Raptor", Harley Davidson, and Limited editions.
- License Plate Relocator PN#32-0065 (sold separately) for "Eco Boost" models.
- Excludes models with "Adaptive Cruise (Speed) Control", or Forward Collision Warning Systems that feature grille mounted laser control sensors.
- Requires lower bumper grille trimming for install on 2010-2012 models.
- May interfere with function of front parking sensor if equipped.

